




Installation Instructions for WSS-4

Important Installation Instructions

1. Locate your existing filter by opening the filter cover and remove it by turning the filter counter clockwise a full ¼ turn.




2. To prevent water spillage on the filter tray, remove the filter by pulling it straight out.

3. Remove sanitary cap from new filter.

IMPORTANT: Pre-condition the filter by submerging the filter in a sink full of water for 30 minutes. This will relieve any trapped air bubbles within the filter and prime the filter for best performance.




4. Insert the new filter into the refrigerator filter housing at an angle as shown in diagram A.




5. Turn filter 90 degrees clockwise until the arrows on the filter knob align with the arrows on the refrigerator as shown in diagram B.

Note: Please ensure the filter is fully installed as it is required to activate the internal water valve. If the filter is not properly installed, you may experience a slow flow or a chattering noise. If this occurs, please uninstall and reinstall the filter ensuring the filter is fully installed. It is recommended to purge the air that may be trapped inside of the new filter to prevent leakage. To purge the air, completely submerge the filter in a bowl or container of water and leave submerged for 45 minutes to 1 hour.



6. Run approximately 2.5 gallons of water from the dispenser periodically to clear the system and to receive a good flow. If the water flow is slower than usual, please repeat Step 4.



Note: Initial flow rate may be slower than expected. Full flow rate should be restored within 24-36 hours.

7. Check the filter for any noticeable leaks. If leaks are detected, please repeat Step 4.

8. To reset the filter monitor, press and hold the Filter Reset button for 3 seconds.

Reset



Specifications

Flow Rate:	.5 gpm (1.89 lpm)
Operating Temperature:	33°-100°F (0.6°-38°C)
Operating Pressure:	30-100 psi (207-689 kPa)
Life:	6 Months or 300 gallons (1,136 liters)



This WSS-4 is Tested and Certified by NSF International against NSF/ANSI Standard 42 for the reduction of chlorine taste and odor.



This WSS-4 is Tested and Certified by IAPMO R&T against NSF/ANSI Standards 42, 53 & 372, for the reduction of Chlorine taste and odor, Lead, Cyst, VOC's, Mercury, Asbestos. Refer to Performance Data Sheet for complete list of claims.

For further questions or assistance please call (866) 218-8473.

Warning: To reduce the risk of property damage from water leakage, the filter bypass plug **MUST** be used when a filter replacement cartridge is not installed. For cold water applications only. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

Protect from freezing. REPLACE FILTER EVERY 6 MONTHS, OR IF BAD TASTE OR ODOR OCCUR.
Systems Certified for cyst reduction may be used on disinfected waters that may contain filterable cysts.

Installation shall comply with applicable state and local regulations.

The risk associated with small parts can cause choking if swallowed.
Keep children away from small parts during the replacement of the water filter.

Aquamor, LLC, 42188 Rio Nedo, Temecula, CA
www.watersentinelfilters.com